

MODEL 3021A

INSTALLATION & MAINTENANCE MANUAL

CONTROL CONCEPTS, INC. 2 YEAR LIMITED WARRANTY

CONTROL CONCEPTS, INC. warrants that the products delivered will be as described in the sales order or contract.

CONTROL CONCEPTS, INC. warrants to the original user that CONTROL CONCEPTS, INC. products will be free from defects in materials and workmanship for a period of two (2) years after the date CONTROL CONCEPTS, INC. ships such products.

If any CONTROL CONCEPTS, INC. product is found to be defective in material or workmanship during the applicable warranty period, CONTROL CONCEPTS, INC.'s entire liability, and purchasers sole and exclusive remedy, shall be the repair or replacement of the defective product at CONTROL CONCEPTS, INC.'s election. CONTROL CONCEPTS, INC. shall not be liable for any costs or expenses, whether direct or indirect, associated with the installation, removal or re-installation of any defective product. All shipping and freight costs are the responsibility of the customer. CONTROL CONCEPTS, INC.'s limited warranty shall not be effective or actionable unless there is compliance with all installation and operating instructions furnished by CONTROL CONCEPTS, INC., or if the products have been modified or altered without the written consent of CONTROL CONCEPTS, INC., or if such products have been subject to accident, misuse, mishandling, tampering, negligence or improper maintenance. Any warranty claim must be submitted to CONTROL CONCEPTS, INC. in writing within the stated warranty period.

CONTROL CONCEPTS, INC.'s limited warranty is made in lieu of, and CONTROL CONCEPTS, INC. disclaims all other warranties, whether expressed or implied, including but not limited to any IMPLIED WARRANTY OF MERCHANTABILITY, ANY IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE, any implied warranty arising out of a course of dealing or of performance, custom or usage of trade.

CONTROL CONCEPTS, INC. SHALL NOT, UNDER ANY CIRCUMSTANCES BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, LOSS OF PROFITS, REVENUE OR BUSINESS) OR DAMAGE OR INJURY TO PERSONS OR PROPERTY IN ANY WAY RELATED TO THE MANUFACTURE OR THE USE OF ITS PRODUCTS. The exclusion applies regardless of whether such damages are sought based on breach of warranty, breach of contract, negligence, strict in tort, or any other legal theory, even if CONTROL CONCEPTS, INC. has notice of the possibility of such damages.

By purchasing CONTROL CONCEPTS, INC.'s products, the purchaser agrees to the terms and conditions of this limited warranty.

WARNING: The Control Concepts, Inc. power controllers use power thyristors to switch voltage to the connected load. Line voltage must be assumed at the output terminals at all times, even when the control signal has been removed and the load voltage appears to be off. It has been mandated by the National Electrical Code and the Occupational Safety and Health Act of 1970 that a physical disconnect be opened ahead of all remotely actuated controls before performing any maintenance work on the controller or its connected load.

PROPRIETARY DATA

© Copyright 2020, Control Concepts, Inc. Chanhassen, MN 55317

The information and design disclosed herein are the property of Control Concepts, Inc. and may not be used, reproduced or disclosed in any form except as granted in writing by:

CONTROL CONCEPTS, INC
8077 CENTURY BLVD
CHANHASSEN, MN 55317
PHONE: (952) 474-6200
TOLL FREE: (800) 765-2799
FAX: (952) 474-6070
www.ccipower.com

TABLE OF CONTENTS

DESCRIPTION:.....	4
THEORY OF OPERATION:.....	4
INSTALLATION:	4
ELECTRICAL CONNECTIONS:.....	5
CONTROL SIGNAL CONNECTIONS:	5
TROUBLE SHOOTING:	8
CAUTION:	8
SPECIFICATIONS:.....	8
MODEL No. IDENTIFICATION:.....	8
REFERENCE DRAWINGS:.....	8
MANUFACTURED BY:.....	8

DESCRIPTION:

The model 3021A controller is a three-phase distributive zero-cross SCR controller. Distributive zero-cross control implies that the load voltage is switched on or off only when the instantaneous value of the sinusoidal supply voltage is zero and that the load power is controlled by varying the number of electrical cycles that power is applied to and removed from the load.

The controller is capable of accepting mA command signals, DC voltage signals, or it may be controlled by a potentiometer. The command signal input is isolated from the line and load voltages.

THEORY OF OPERATION:

THE SCR

The heart of the SCR power controller is the SCR (silicon controlled rectifier, sometimes referred to as a thyristor).

The SCR has two states, ON and OFF, and allows current to flow in only one direction when turned on. SCR's can remain in the off state even though the applied potential may be several thousand volts; in the on state, they can pass several thousand amperes. When a small signal is applied between the gate and cathode terminals (Figure 1), the SCR will turn on in 10-100 microseconds. Once turned on, it will remain on until the current through it is reduced below a very low value, called the holding current.




Figure 1. SCR Symbol.

Because the SCR allows current to flow in only one direction, two SCR's are connected in a "back to back" configuration to control AC current (Figure 2).




Figure 2. SCR AC Switch.

ZERO-CROSS OPERATION

In zero-cross control, the load power is turned on or off only when the instantaneous value of the sinusoidal waveform is zero. Load power is controlled by switching the SCRs "on" for a number of complete electrical cycles, and then "off" for a number of complete electrical cycles. The circuit determines the ON versus the OFF time of the silicon controlled rectifiers (SCRs) such that the load power is linear with the command signal. The circuit at 50% power will cause the SCRs to be "on" for 3 cycles and "off" for 3 cycles. At higher power levels, the SCRs are ON for more cycles and OFF for 3 cycles. At lower power levels, the SCRs are ON for 3 cycles and OFF for more cycles. The SCRs are turned ON and OFF only at the beginning and end of each electrical cycle.




Figure 3. Distributive Control.

INSTALLATION:

The controller must be mounted on a vertical surface with the fins oriented vertically such that air will flow over the heat dissipating fins. The plug-in connectors may be removed by pulling them straight away from the circuit board. For optimum performance of the controller, 24Vac must be supplied by a transformer which is connected to the same supply used to power the load.

ELECTRICAL CONNECTIONS:




Figure 4. Electrical power connections.

CONTROL SIGNAL CONNECTIONS:




Figure 5. Command Signal inputs.

* Valid only when ordered as an option.

INSTALLATION DRAWINGS:





Figure 6. Model 3021A - 10, 20, 30 AND 40 AMPS.
(BOTH ASSEMBLIES REQUIRED)

INSTALLATION DRAWINGS:



**Figure 7. Model 3021A - 70 AMPS
(BOTH ASSEMBLIES REQUIRED)**

TORQUE TABLE FOR USD CONNECTORS	
Wire Size	Recommended Torque
10 -14 ga	35 in-lbs
8 ga	40 in-lbs
4 - 6 ga	45 in-lbs
2-3 ga	50 in-lbs

TROUBLE SHOOTING:

Control Concepts has field service engineers who can aid in determining the cause of controller problems. Please call with any problems or questions you may have.

CAUTION:

High voltage exists on the supply and load terminals of this controller and may exist on other equipment located near the controller. Use extreme caution to avoid electrical shock.

The LED located on the controller circuit can be used to aid in determining problems. This LED varies in intensity proportional to the command signal and therefore should be proportional to the load voltage.

THE FOLLOWING ARE SYMPTOMS AND POSSIBLE CAUSES:

NO LOAD POWER AND LED IS NOT ON:

Determine that the command signal is applied to the correct terminals on the circuit board. (See Fig. 5, Page 2.) Make sure that 24 Volts AC is applied to the circuit. If another circuit board is available, a substitution may show whether the circuit board is at fault.

NO LOAD POWER; LED INTENSITY CAN BE

VARIED: Determine that all fuses are "OK". If the voltage across the SCR module is equal to the line voltage the SCR module has probably failed. NOTE: If a replacement SCR module is ordered, specify the voltage, current rating and serial number of the failed controller.

LOAD POWER IS MAXIMUM AND CANNOT BE REDUCED:

LED IS OFF: Remove the 24Vac plug in connector. If the load still has power, the SCR module has probably failed as a short, allowing full power to be applied to the load. To determine if the SCR module has shorted, remove power and then the line and load connections. Measure the resistance across the line and load terminals on the SCR module. If the resistance is less than 10,000 ohms, the module has failed. NOTE: If a replacement SCR module is ordered, specify the voltage, current rating and serial number of the failed controller.

LED IS ON: Determine that the command signal is adjusted to zero, or pull out the 4 terminal connector to remove the command signal. If the LED does not go off, the circuit card has probably failed.

MAXIMUM LOAD VOLTAGE CANNOT BE

OBTAINED: Determine that the primary of the 24Vac transformer is connected to the same supply as the controller and load. Typically, this problem is caused by the primary being connected across the load and line connections on the controller. Measure the 24 Vac supply at the circuit board.

SPECIFICATIONS:

CURRENT RATING The (LOAD CURRENT) term within the model number specifies the maximum continuous RMS current rating at a 55°C maximum operating temperature.

COMMAND SIGNAL	Input Resistance
0 to 5 Vdc	100 K
0 to 10 Vdc	200 K
4/20 mA	300 ohms
Potentiometer	200 K

(1K, 1/2 watt pot. recommended, 20K maximum permissible.)

ISOLATION: 2500 Vrms input signal to load and line voltages.

CONTROL MODE: Zero-cross, distributive.

LINE VOLTAGE COMPENSATION: The average load voltage remains constant within 2% over line voltage changes of +10% to -15%.

FUSES: It is recommended that the controller and the load be protected with fast acting fuses such as the JJN and JJS, class "T", series of fuses. Contact Control Concepts for price and delivery information.

MODEL No. IDENTIFICATION:

3021A-(VOLTAGE)-(LOAD CURRENT)-(XX)

(VOLTAGE) = Rated operating voltage

12 = 120 Vac

24 = 240 Vac

48 = 480 Vac

(LOAD CURRENT) = Current applied to load at 100% command signal.

(XX) = Command signal: 0 to 5 Vdc, 0 to 10 Vdc, 4 to 20mA or potentiometer.

REFERENCE DRAWINGS:

B1000359B1 Schematic
AS1401 Transformer Inst. Dwg.

MANUFACTURED BY:



TEL: (952) 474-6200

(800) 765-2799

FAX: (952) 474-6070

www.ccipower.com

8077 Century Blvd
Chanhassen, MN 55317, USA